





Dual wavelength heterodyne LDA for velocity and size distribution measurements in ocean water flows

Hongwei ZHANG^{1,2,3}, Ziwang Ll², Xiangchen CHEN² Jintao Ll², Kailin ZHANG², Songhua WU^{2,3,4}, Yan HE¹, Weibiao CHEN¹, Junwu TANG³

zhanghongwei8944@ouc.edu.cn


Shanghai Institute of Optics and Fine Mechanics, Chinese Academy of Sciences
College of Marine Technology, Ocean University of China
Pilot National Laboratory for Marine Science and Technology (Qingdao)

[10].[Measurement techniques and observations of Ocean properties]


[29-June, 2022], [12:15 UTC]


[Wednesday_10_P01]

The 30th International Laser Radar Conference (ILRC) virtual conference, June 26th – July 1st, 2022.




Essential Ocean Variables






Configuration of the LDCP system







The sensor is an extension of the principle of Laser Doppler Anemometry (LDA). It is non-intrusive, highly accurate and able to highly resolve the flow both in the time and spatial extensions.



Field observation campaign








Field observation campaign

Table 1. Specification of the LDCP system and Propeller current meter.


Specification	LDCP system	Propeller current meter
Resolution	0.1 cm	1 cm
Speed range	0.1 cm – 10 m	1 cm - 3 m
Data rate	0.1 s	30 s
Weight	20 kg	10 kg



The 30th International Laser Radar Conference (ILRC) virtual conference, June 26th – July 1st, 2022.

0.2

1) Size distribution of small-scale particles



2

3

r/d

5

4




Table 2. Categories of algae utilized in the laboratory observation campaign.


No	Categories	Size distribution
1	Chlorella	Single-celled green algae, Spherical, Oval, diameter range: 3~8µm
2	Halophila	Single-celled green algae, Pear shaped, Oval, diameter range: 3~14µm
3	Diatom	Single-celled flagellate, diameter range: 3~20µm
4	Flat algal	Single-celled green algae, diameter range: 9~24µm

rnational Laser Radar Conference (ILRC) virtual conference, June 26th – July 1st, 2022.

Conclusion and Outlook



2) Size distribution of large-scale particles



In terms of the large-scale suspended particles size distribution measurement can be obtained by combining laser-induced fluorescence and laser Doppler velocimetry. In the subsequent research, the technology will be used to detect the particle size of large suspended particles.

The specific conclusions are as follows:

- 1. Good quality measurements were demonstrated in laboratory measurement. Suspended particles with diameter from 2 μm to approximately 9 μm can be identified by the *burst signal visibility method*.
- 2. The LDCP system could obtain the *velocity* and *concentration* of the suspended particles (tracer particles or seeding particles) *simultaneously*, the *fluxes of organic carbon* could be calculated by integrating the velocity and concentration information.